

Wi-Fi Video Doorbell *Notifications*

From the main screen, click the 'Cog' icon to enable "Basic Config" & "Function Settings" screen







Notifications

- *Message on/off*
- *Do not or Notify me*
- *Push Notification Period, (Time)*
- *Alarm Type*
- *Device call Notifications*
- *Offline Notification*

Select the 'Notifications' arrow >







Turn on to receive notifications

Notify or don't notify you?


Schedule notification times






Alarm Message Type:


- Motion Detection, *(this will notify you when anything moves).*
- Human
- Vehicle
- Lottering
- Package Detection
- Other Alarms




Package Detection is a new feature, so the functionality may be updated and improved as the system develops. We will continue to review this feature and make any necessary changes as further improvements become available.

You will need to set the detection area in the **AI** section witin the Function section








Draw the area you wish to monitor for Package Detection. In our example, we have simulated a doorstep and selected the area highlighted by the red box for monitoring.

Dont forget to click the save icon



Note 'Smart Motion Detection' and 'Anti-Theft Protection' is covered in our AI help file ;)

Other Alarms currently only has the Tamper alarm available. However, this may be expanded in future system updates as additional alarm functions become available.

